

FM10 / FM08- Keyboard Base Plate


PN# 98K000A00060

Features:


- Keyboard base plate is designed by Winmate for Keyboard mounting solutions
- 4 VESA Holes on the plate to device and 4 AMPS holes to RAM Ball (Size C)
- 135° angle fixed adjustment to avoid cabling installation

Installing the keyboard on the keyboard base plate:

- Step 1. Position the Vertical part of the keyboard base plate on the rear of the FM10 / FM08 aligning the holes on the back of the FM10 / FM08 with the holes on the vertical part of keyboard base plate. Attach with four M4 screws.
- Step 2. Position the sloped part of the keyboard base plate on the RAM balls, aligning the AMPS holes on the RAM ball (size C) with the holes on the sloped surface of keyboard base plate. Attach with for M4 screws.
- Step 3. Insert the RAM ball into the RAM arm and Insert another RAM ball into the other side of RAM arm and then tighten the knob on the RAM arm.
- Step 4. Mount the keyboard into the RAM ball.




Keyboard based plate
PN# 821009131600



a.FM10 / FM08
b.Vertical part of Keyboard base plate
c.Sloped part of Keyboard base plate
d./ f. RAM balls
e.RAM arm
g.Keyboard

Mechanical Drawing



Part numbers	Parts	amount of parts
PN# 98K000A00060	Keyboard base plate	x 1
	M5 x 12mm	x 5*
	M4 x 14mm	x 5*
PN#821009131600	keyboard base plate	x 1
PN#913511101149	SUS304 M5x12mm Screw (vertical part of base plate)	x 5*
PN#91351110111W	SUS304 M4x14mm screw (sloped part of base plate)	x 5*

*note: 5 screws (4 screws for mounting and 1 screw for spare)